

IDLE SPEED


See your authorized Honda dealer for regularly scheduled carburetor adjustments, including individual carburetor adjustment and synchronization.

NOTE:

* The engine must be warm for accurate idle speed adjustment. Ten minutes of stop-and-go riding is sufficient.

1. Warm up the engine, shift to neutral and place the motorcycle on its center stand.
2. Adjust idle speed with the throttle stop screw (1).

Idle Speed: 1300 ± 100 rpm
(In neutral)



(1) Throttle stop screw

(A) Increase rpm

(B) Decrease rpm