

## Brake pads

(Front wheel)

Squeeze the brake lever several times, then check both pads for excessive wear.

### Inner pad inspection:

If the end of the wear indicator aligns with the red zone, the pad is worn excessively and must be replaced with a new one.

#### NOTE:

\* Use only genuine Honda replacement brake pads offered by authorized Honda dealers or its equivalent. See your authorized dealer for brake service.

- (1) Range
- (2) Wear limit
- (3) Red zone
- (4) End of wear indicator

