

Service and maintenance

ITEM	FREQUENCY	Pre-ride check	500 Km.	1,500 Km.	3,000 Km.	4,500 Km.	6,000 Km.	Every 6 months	Yearly check	Every 2 years	Remarks
Fuel filter									I		
Clean under the front suspension fender								I			
Air cleaner			C	R	R	R	R				Check the air cleaner after riding in dusty areas.
Spark Plug					I		R				
Valve clearance			I		I		I				
Crankcase breather				C	C	C	C		C		
Engine oil filter			R	R	R	R	R		R		
Engine oil filter screen			C	C	C	C	C				
Engine idle speed			I	I	I	I	I		I		
Radiator coolant			I	I	I	I	I		I	R	
Cooling system			I	I	I	I	I		I		
Drive chain slider / tensioner			I	I	I	I	I				Check the item after riding in adverse conditions and dusty areas.
Drive / driven sprocket			I	I	I	I	I				
Drive chain slider			I	I	I	I	I				
Brake system			I	I	I	I	I		I		
Clutch fluid			I	I	I	I	I		I	R	
Rear suspension			I	I	I	I	I		I		Check the items more often when riding in adverse conditions and dusty areas.
Damper linkage / rods			I	I	I	I	I		I		
Fork oil										R	
Steering pipe bearing			I	I	I	I	I		I		
Wheel bearings					R		R				
Nuts, bolts and fasteners			I	I	I	I	I		I		