


Frame servicing

Spokes: Check spoke tension frequently between the first few rides. As the spokes, spoke nuts and rim contact points seat-in, the spokes may need to be retightened.

Once past this initial seating-in period, the spokes should hold their tension. Still, be sure your race maintenance program includes checking spoke tension and overall wheel condition on a regular basis.



Torque: 17 N·m (1.7 kgf·m, 12.5 lbf·ft)

(a) 30 ± 0.5 mm