


## FRONT WHEEL/SUSPENSION

---

Replace the bulbs, if necessary.

If a replacement bulb does not light, check the wiring for a short or open circuit, or check for loose connections.



BULBS

## ASSEMBLY/INSTALLATION

Lubricate the speedometer cable with light oil before reconnecting.

Assemble and install the instruments in the reverse order of disassembly and removal.

